

		Steam Inlet Pressure (psi)									
		5		10		15		30		50	
Temperature Rise (°F)	Model Prefix	Inlet Steam Valve size	Condensate Trap size (PVI PN)	Inlet Steam Valve size	Condensate Trap size (PVI PN)	Inlet Steam Valve size	Condensate Trap size (PVI PN)	Inlet Steam Valve size	Condensate Trap size (PVI PN)	Inlet Steam Valve size	Condensate Trap size (PVI PN)
40 to 120	10	1-1/2	3/4 (68466)	1	3/4 (68466)	1	3/4 (68466)	1	3/4 (68470)	1	1-1/4 (68476)
	20	2	1-1/2 (68468)	2	1-1/4 (68467)	1-1/2	1-1/4 (68467)	1-1/2	1-1/2 (68471)	1	1-1/4 (68476)
	40	2-1/2	2 (68469)	2-1/2	1-1/2 (68468)	2	1-1/2 (68468)	2	2 (68472)	1-1/2	2 (68477)
	60	Contact factory	Contact factory	2-1/2	2 (68469)	2-1/2	2 (68469)	2	2 (68472)	2	2 (68477)
	80	Contact factory	Contact factory	Contact factory	Contact factory	2-1/2	2 (68469)	2-1/2	2 (68472)	2	2 (68477)
40 to 140	10	1-1/2	3/4 (68466)	1	3/4 (68466)	1	3/4 (68466)	1	3/4 (68470)	1	1-1/4 (68476)
	20	2	1-1/2 (68468)	1-1/2	1-1/4 (68467)	1-1/2	1-1/4 (68467)	1	1-1/2 (68471)	1	1-1/4 (68476)
	40	2-1/2	1-1/2 (68468)	2	1-1/2 (68468)	2	1-1/2 (68468)	2	1-1/2 (68471)	1-1/2	1-1/4 (68476)
	60	Contact factory	Contact factory	2-1/2	2 (68469)	2-1/2	2 (68469)	2	2 (68472)	2	2 (68477)
	80	Contact factory	Contact factory	Contact factory	Contact factory	2-1/2	2 (68469)	2-1/2	2 (68472)	2	2 (68477)
40 to 160	10	1-1/2	3/4 (68466)	1	3/4 (68466)	1	3/4 (68466)	1	3/4 (68470)	1	3/4 (68475)
	20	2	1-1/4 (68467)	1-1/2	1-1/4 (68467)	1-1/2	1-1/4 (68467)	1	1-1/2 (68471)	1	1-1/4 (68476)
	40	2-1/2	1-1/2 (68468)	2	1-1/2 (68468)	2	1-1/2 (68468)	1-1/2	1-1/2 (68471)	1-1/2	1-1/4 (68476)
	60	2-1/2	2 (68469)	2-1/2	2 (68469)	2-1/2	2 (68469)	2	2 (68472)	2	2 (68477)
	80	Contact factory	Contact factory	2-1/2	2 (68469)	2-1/2	2 (68469)	2-1/2	2 (68472)	2	2 (68477)

- Contact PVI if steam pressure and /or required temperature rise differ from those listed.

